

Work Order ID 81385

81385

Page 1

March-14-12 7:44:43 AM

Item ID: D350-616-011

Accept

N900040100

Setup Start

NS1

Revision ID:

Item Name: Emergency Litter

Stop

NS2

Start Date: 13/03/2012 Start Qty: 1.00

1

Cust Item ID:

Required Date: 27/03/2012 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: *MLJ*

Date: *12/03/14*

Tooling:

Date:

Run Start

NR1

QC:

Date:

SPC (Y/N):

Date:

Stop

NR2

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

d350-616

E

x SP

0.00

100

100

DC

Document Control

Memo

0.00

Photocopy bluefile and create labels per PPP D350-616-011
CHG004

See label 13

22 for MLJ 12-4-12

110

Pick Kit

0.00

110

Packaging

Packaging

Memo

0.00

1x

SP 12-04-11

120

QC4- 100% Inspect kits for completeness

0.00

120

QC

Quality Control

Memo

0.00

See label 13

(H)

Dart Aerospace Ltd

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____
 Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 81385***81385***

Page 2

March-14-12 7:44:43 AM

Item ID: D350-616-011

Accept

N900040100Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Emergency Litter

Start Date: 13/03/2012 Start Qty: 1.00

1

Cust Item ID:

Required Date: 27/03/2012 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals:

Process Plan:

Date:

Tooling:

Date:

Run Start ***NR1***

QC:

Date:

SPC (Y/N):

Date:

Stop ***NR2***Sequence ID/
Work Center IDOperation
DescriptionSet Up/
Run HoursTool ID Tool # Plan
Code Accept
Qty Reject
Qty Reject
Number Insp.
Stamp

130

0.00

130

Packaging

Memo

0.00

Packaging

Identify and pack for shipping as per PPP D350-616-011

Location: 13PPP Rev: 8

140

QC21- Final Inspection - Work Order Release

0.00

140

QC

Memo

0.00

Quality Control

12
SP 12-04-13

12 14 13

MR
12-04-13

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

March-14-12 7:44:47 AM

Page 1

Work Order ID: 81385

81385

Parent Item: D350-616-011

D350-616-011

Parent Item Name: Emergency Litter

Start Date: 13/03/2012

Required Date: 27/03/2012

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP E03.04.04ReformatKJ/RF
IPP Rev:F 08-12-10 rev.E as per dwg DD verified by:ec

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D2370		Manufactured	No				Each	4.0000		1			
D2370									**	SP			
Litter Assembly													

				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
D2493		Manufactured	No		ST331	4							
D2493					78629	4				1X			
Patient Stop Assembly							Each	5.0000	**	SP			

					<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>				
D350-616-013		Manufactured	No		ST224	5							
D350-616-013					78617	5				1X			
Deck Plate and Tie Down							Each	0.0000	**	B81387			

SP12-04-11

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

REFERENCE ONLY

QTY - 011	Qty - 013	Qty - 015	Part Number	Description
X			D350-616-011	Full Litter Kit
1	X		D350-616-013	Deck Plate and Tie Down Kit
	1	X	D350-616-015	Deck Plate Kit
		1	D2344	DECK PLATE (AFT)
		4	D2348	WEAR PLATE (KEY WAY)
		1	D2353	STIFFENER
	1		D2360	LITTER TIE DOWN (LOCKING)
		1	D2364	DECK PLATE (FWD)
		2	D2365	WEAR PLATE (PIP PIN)
		1	D2369-1	LOCATOR PLATE
		1	D2369-3	LOCATOR PLATE
1			D2370	LITTER ASSEMBLY
1			D2493	PATIENT STOP
	1		D3179-041	LITTER TIE DOWN (NON-LOCKING)
		1	D3494-1	STUB COVER
		25	MS20426AD4-5	RIVET
		25	MS20426AD4-6	RIVET
		6	MS20426AD5-7	RIVET
		6	MS20426AD5-8	RIVET
		15	MS20601AD4W2	BLIND RIVET (or CR9162-4-2)
		30	MS20601AD4W3	BLIND RIVET (or CR9162-4-3)
		6	MS21042L3	NUT (or MS21042-3)
		6	MS24693-C273	SCREW (or MS24693-273)
		22	MS24693-C48	SCREW (or MS24693-48)
		4	MS35207-264	SCREW
		10	NAS1149D0363J	WASHER (or AN960JD10)

RELEASED
08/11/21 NW

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

APPROVED
BY: *[Signature]*
D. SHEPHERD (DE # 02)

DATE: 08.11.07
CERT. NO.: SH96-10
ISSUE NO.: 2

E	MAKE DSI 9310 STANDARD; D3179-041 REPLACES D2350	RF	08.11.07
D	ADD D3494-1 STUB COVER	MB	06.01.19
C	ADD DSI 9112/9117/9130/9236/9310	MB	06.01.10
B	ADD VIEW OF D2493 TO SHEET 9	BW	96.01.09
A	NEW ISSUE	BW	95.02.20
REV.	DESCRIPTION	BY	DATE

DESIGN	BW	DART AEROSPACE LTD	
DRAWN	RF	HAWKESBURY, ONTARIO, CANADA	
CHECKED	DS	DRAWING NO.	REV. E
MFG. APPR.	N/A	D350-616	SHEET 1 OF 12
APPROVED	DS	TITLE	SCALE
DE APPR.	<i>[Signature]</i>	AS350/355 LITTER KIT INSTALLATION	NTS
DATE	08.11.07	COPYRIGHT © 1995 BY DART AEROSPACE LTD	
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.			